


# MODEL : LMF-40AC



L1670

## PARTS LIST (LMF-40AC)

\*WHEN ORDERING SPARE PARTS, PLEASE STATE ITEM No., PART No. AND DESCRIPTION.

ITEM	PART NO	DESCRIPTION	ITEM	PART NO	DESCRIPTION	ITEM	PART NO	DESCRIPTION
1	HS0530B	HEX. SOC. HD. BOLT+SW	50	11705001	MAGAZINE			
3	13900305	CAP	51	HS0408B	HEX. SOC. HD. BOLT+SW			
4	12100401	SEAL**	52	11705201	TAIL COVER			
5	12100501	SPRING**	53	11505301	PUSHER			
6	OR1425R	O RING**	54	12105401	SPRING**			
7	11100701	CAP SEAL**	55	12105501	NAIL GUIDE LINER			
8A	12100801A	HEAD VALVE ASM.	57	HS0406B	HEX. SOC. HD. BOLT			
11	OR3224R	O RING**	61A	13206101A	BRACKET ASSEMBLY			
13-1	OR1830R	O RING**	64	HS0516B	HEX. SOC. HD. BOLT			
13-2	11501303	PISTON RING	65	LN0500N	LOCK NUT			
14A	11501401A	DRIVER ASSEMBLY**	66	11106601	COVER			
18	OR4630R	O RING**	67	12106401	AIR PLUG			
19-1	16701901	CYLINDER	68	OR4030R	O RING**			
19-2	16701901G	CYLINDER	71	US0506B	UM. HD. BOLT			
19-3	11101903	COLLAR	72	FW0512W	FLAT WASHER			
20	11502001	BUMPER**	73	12103301	SEAL			
21	OR3018R	O RING**	74	13907403	EXHAUST COVER			
23	11102309	BODY	76	RP3018S	ROLLED PIN			
24	OR1919H	O RING**						
25	12102501	JOINT GUIDE						
26	11002601	SPRING						
27	11002702	GUIDE SAFETY LEVER						
31	11003101	SAFETY LEVER						
32	12103202	STEPPED PIN						
41A	13104101A	LATCH**						
42	US0520B	UM. HD. BOLT						
43	SW0500W	SPRING WASHER						
44A	11504401A	DRIVER GUIDE COVER ASM						
44	11504401	DRIVER GUIDE COVER						
45	12104501	SET PLATE						
46	HS0412B	HEX. SOC. HD. BOLT						
47	11504701	DRIVER GUIDE						
48	11704801	MAGAZINE COVER						
49	SS0412S	SET SCREW						

NO : L1670