



pos.	codigo	descripcion	cod. Fabrica	pos.	codigo	descripcion	L1751 cod. Fabrica
1	R100201	TORNILLO	US0506B	37	R100232	VALVULA SUP.DISPARADOR	20403901
2	R100202	ARANDELA	FW0512W	38	R100233	JUNTA	OR0519R
3	R100203	RETEN	12103301	39	R100234	JUNTA	OR0618R
4	R100204	DIFUSOR	13907403	40	R100235	JUNTA	OR0819R
5	R100205	TORNILLO	HS0520BW	41	R100236	VALVULA INF.DISPARADOR	20404301
6	R100206	CIERRE CILINDRO	17300604	43	R100237	MUELLE	15108301
8	R100207	ESPACIADOR	13600801	42	R100238	JUNTA	OR2515H
9	R100208	TOPE PISTON	13600901	44	R100239	VASTAGO DISPARADOR	20404601
10	R100209	MUELLE	13601001	45	R100240	JUNTA	OR2515H
11	R100210	JUNTA	OR3420R	46	R100241	TORNILLO	HS0516B
12	R100211	VALVULA	13601201	47	R100242	PASADOR	RP3020S
13	R100212	JUNTA	OR4720R	48A	R100243	CIERRE TAPA LENGUETA	13104101A
14	R100213	RETEN	13601401	49	R100244	PASADOR	BP0422P
15	R100214	JUNTA	OR3435R	50	R100245	TAPA LENGÜETA	13605001
16A-1	R100215	PISTON LT1650AC	13601601A	51	R100246	GUIA LENGUETA	17505104
18	R100216	ESPACIADOR CILINDRO	17301801	52	R100247	TAPA CARGADOR	13605203
19	R100217	JUNTA	OR6026R	53	R100248	TORNILLO	SS0412S
20	R100218	JUNTA	OR4325R	54	R100249	CARGADOR	13605402
21-1	R100219	CILINDRO	20402101	55	R100250	TORNILLO	HS0408BW
22	R100220	BUMPER	17302201	56	R100251	TOPE TRASERO CARRO	13105201
24	R100221	JUNTA PAPEL	17302401	57	R100252	EMPUJADOR	13705301
25	R100222	CIERRE PUNTA	10902501	59	R100253	MUELLE	12105401
26	R100223	JUNTA	OR1919H	60	R100254	LINEA GUIA	13606001
27	R100224	CUERPO	20402701	61A	R100256	CIERRE CARRO	13206101A
28	R100225	PASADOR	12103202	69	R100257	TUERCA	LN0500N
31	R100226	GUIA MUELLE	12102601	70	R100258	JUNTA PAPEL	15107001
32A	R100227	GUIA SEGURO	13002701A	71	R100259	TAPA TRASERA CUERPO	15107101
33	R100228	MUELLE	12102801	79	R100260	JUNTA	OR1624R
34	R100229	SEGURO	13603401	80	R100261	CIERRE DISPARADOR	20404901
35	R100230	JUNTA	OR1224R	82A	R100262	GATILLO	15104502A
36	R100231	JUNTA	OR1415R				