



L1330

pos.	codigo	descripcion	cod. Fabrica	pos.	codigo	descripcion	cod. Fabrica
1	R140001	TORNILLO	HS0520B	35A-4	R140029	VASTAGO DISPARADOR	11003503
3	R140003	CIERRE CABEZA	13900306	35A-5	R140030	JUNTA	OR2515H
4	R140004	RETEN	12100401	35A-6	R140031	JUNTA	OR1119R
5	R140005	MUELLE	12100501	35A-7	R140032	CAJA INF.DISPARADOR	11003803
6	R140006	JUNTA	OR1425R	35A-3	R140033	MUELLE	11006901
7	R140007	JUNTA PLASTICA	11100701	35A-8	R140034	GATILLO	15104501A
8A	R140008	VALVULA	13900801	41A	R140035	CIERRE TAPA GUIA	13104101A
11	R140011	JUNTA	OR3224R	46	R140036	TORNILLO	HS0520B
13	R140012	JUNTA	OR2635R	44A	R140038	TAPA GUIA LENGUETA	13104401
14-A2	R140013	PISTON LT 50 AC	13301402A	45	R140039	PLACA B	12104501
18	R140014	JUNTA	OR4630R	47	R140041	GUIA LENGUETA	13704701
19-1	R140015	CILINDRO	13301901	48	R140042	TAPA CARRO	13704801
19-3	R140016	COLLAR	13901903	49	R140043	TORNILLO	SS0412S
20	R140017	BUMPER	13902001	50	R140044	CARRO CLAVOS	13705001
21	R140018	JUNTA	OR3520R	51	R140045	TORNILLO	HS0408B
23	R140020	CUERPO	11102309	52	R140046	TOPE TRASERO CARRO	13105201
24	R140021	JUNTA	OR1919H	53	R140047	EMPUJADOR	13105301
25	R140022	CIERRE PUNTA	13702501	54	R140048	MUELLE	12105401
26	R140023	MUELLE SEGURO	11002601	55	R140049	BARRA GUIA	12105501
27	R140024	GUIA SEGURO	11002702	61A	R140055	SOPORTE COMPLETO	13206101
31	R140025	SEGURO	13203101	64	R140057	TORNILLO	HS0408B
32	R140026	PASADOR	12103202	66	R140061	TAPA TUERCA	11106601
35A-5	R140027	JUNTA	OR0319R	68	R140062	JUNTA	OR4030R
35A-2	R140028	CAJA SUP. DISPARADOR	11003401	74	R140066	DIFUSOR AIRE	13907403