



*R : APPLY LOCTITE 271
 *B : APPLY LOCTITE 242

L32100 07/11/2008

1	R252001	TORNILLO	US050808B 12	27	R252027	MUELLE	11002601
2	R252002	DIFUSOR AIRE	20900201	28	R252028	GUIA SEGURO	27202701
3	R252003	RETEN	20900301	29	R252029	JUNTA	OR02519N
4	R252004	TORNILLO	HS05080BW25	30	R252030	JUNTA	OR02515V
5	R252005	TORNILLO	SS04070B 06	31	R252031	SEGURO	32103101
6	R252006	CABEZAL CIERRE	20900601	33	R252032	ARANDELA	16103001
7	R252007	RETN	20900701	34	R252033	VAL SUP DISPARADOR	11003401
8	R252008	JUNTA	OR11824N	35	R252034	VASTAGO DISPARADOR	11003503
9	R252009	VALVULA SUPERIOR	20900901	37	R252035	MUELLE	11006901
10	R252010	JUNTA	OR40025N	38	R252036	VAL INF DISPARADOR	11003803
11	R252011	MUELLE	20901101	39	R252037	JUNTA	OR10719N
12	R252012	VALVULA	20901201	40A	R252038	GATILLO	15104501A
13	R252013	TOPE	20901301	44	R252040	TAPA GUIA LENGÜETA	32104401
14	R252014	JUNTA	OR32025N	45	R252042	ARANDELA	SW0500W
15	R252015	JUNTA	OR28035N	46	R252043	TORNILLO	US05080B 10
16A	R252016	PISTON LU G 40 LM	32101601A	47	R252044	GUIA LENGÜETA	32104701
17	R252017	CILINDRO	20901701	48	R252045	TORNILLO	US04070B 10
18	R252018	JUNTA	OR38025N1	50	R252046	CARGADOR	32105001
19	R252019	BUMPER	20901901	51	R252047	EMPUJADOR	32105101
20	R252020	JUNTA PAPEL	20902001	59	R252048	TOPE	32105901
21	R252021	JUNTA	OR01919N	69	R252049	BRAZO ACOPLE	32106901
22	R252022	CUERPO	30302302	70	R252050	MUELLE	32107001
23	R252023	TORNILLO	HS05080BW16	76	R252051	TORNILLO	US04070B 04
24	R252024	CONECTOR AIRE	12106401	85	R252052	PLACA	32108501
25	R252025	CIERRE GUIA,	17102501	87	R252053	MUELLE	32108701
26	R252026	PASADOR	11103201				