


MINI-BELT SANDER



Index No.	Parts No.	Description	Index No.	Parts No.	Description
1	61001	Housing	27	62027	Nipple
2	61002	Guard Body	28	62028	Spring
3	62003	Air Inlet	29	62029	Silencer
4	62004	Lever	30	62030	Screw (M4x25L)
5	62005	Valve Stem	31	62031	Lever Support
6	62006	Adjust Valve	32	62032	Screw (3) (M4x8L)
7	30107	O-Ring (3.9x1.9)	33	40147	Spring Washer (2) (M4)
8	62008	Spring	34	62034	Nut (M4)
9	62009	O-Ring (14.5x1.5)	35	61035	Screw (M3x8L)
10	62010	Spacer	36	61036	Spring Pin (3x10L)
11	62011	Retaining Ring (RTW-18)	37	61037	Screw (M2x5L)
12	61012	Spacer	38	061038	Ball Bearing(2) (684zz)
13	051825	Ball Bearing (607ZZ)	39	61039	Idle Pulley Shaft
14	61014	Rear End Plate	40	61040	Spring
15	61015	Rotor	41	61041	Tension Bar
16	61016	Rotor Blade (4)	42	61042	Bushing
17	61017	Key	43	61043	Idle Pulley
18	61018	Cylinder	44	61044	Spring
19	61019	Front End Plate	45	61045	Bracket
20	061020	Ball Bearing (628ZZ)	46	61046	Screw (M3x6L)
21	61021	Cap	47	61060	Grinding Belt
22	61222	Drive Pulley	48	61048	Spring Pin (2.5x8L)
23	63042	Hexagon Nut (M6x1)	49	61049	Spring
24	61024	Shoe	50	61050	Safety Lever
25	40343	Screw	51	61249	Lock Pin (3x11.8L)
26	61026	Dust Cover			

610-0001