




Index No.	Parts No.	Description	Index No.	Parts No.	Description
1	5D-6192PA01	Motor Housing	40	5D-619240	Flange Nut (M14x2)
2	30102	Spring Pin (3x24)	41	61941	Adjust Screw
3	5D-619203	Air Inlet	42	61942	Adjust Nut
4	6K-301104	Throttle Lever	43	40343-12	Screw (4) (M5x16)
5	5D-619205	Pin	44	5D-619224	Inlet Guide
6	75-725145	Rubber Spacer	45	61945	Spring
7	61907	O-Ring (4.9x2.2)	46	61946	Governor
8	73108	Spring	47	61947	Pendulum (6)
10	75-725146	Valve Stem	48	40317-13	Spring Pin (2) (3x12)
12	61912	Plunger	49	82247	O-Ring (13.5x1.5)
13	030120	Ball Bearing (2) (608zz)	50	522212	Spring
14	5D-619214	Rear Plate	51	522239	Safety Bar
15	61915	Rotor	52	51542	Spring Pin (2x18)
16	61916	Rotor Blade (4)	53	5D-619207	Exhaust Diffuser
17	206106	Spring Pin (2.5x12)	*54	5D-619256	Dead Handle
18	5D-619218	Cylinder		5G-619753	Vibration Reduced Handle
19	5D-619219	Front End Plate	55	619554	Pin Wrench
20	080227	Ball Bearing (6201z)	56	ISTW-7	Retaining Ring (ISTW-7)
21	5D-619008	Gasket	57	5D-619227	Bushing
22	61922	Bevel Gear	58	52236	O-Ring (10.5x1)
23	5D-619228-0001	Gear Housing	59	5D-619208	Spring
24	40344	Spring Washer (4) (M5)	60	5D-619229	Spindle Stop Button
25	62025	Screw (4) (M5x18)	61	82246-12	Set Screw (2) (M5x8)
26	61926	Spacer	*62	OR02700200	O-Ring (27x2)
27	5D-619261	Screw (M6x10)	*63	5D-619247	Clamp
28	030113	Ball Bearing (626zz)	*64	51239	Hose
29	60319	Retaining Ring (STW-10)	*65	5D-619249	Exhaust Hose
30	5D-6192S30	Bevel Gear	66	206011	O-Ring (29.5x2)
31	61931	Wave Washer (VW-10)	68	5D-6192S08	Spring
32	061932	Ball Bearing (6202zz)	69	5D-6192S09	Lock Ring
33	5D-6192S26	Spindle (M14x2)	70	5D-6192S10	Disk Spring
34	61934	Key (3x13)	71	STW27	Retaining Ring (STW-27)
35	5D-6192S11	Spacer	79	5D-619250	Felt Oiler
36	5D-6192S07	Bearing Cap	80	5D-619251	Steady
37	5D-6192S02	Disc Cover	81	5D-619258	Washer
38	5D-619239	Flange (M14)	82	41-401254	Oil Cap (1/8")
39	61048	Spring Pin (2.5x8)			

* Optional Parts

5D-6192P-00S2