


AIR MICRO GRINDER



Index No.	Parts No.	Description	Index No.	Parts No.	Description
1	51601	Housing	17	51617	Pin
2	51602	Rear End Holder	18	51618	Cylinder
3	51603	Air Inlet	19	51619	Lateral Disc
4	51604	Throttle Valve Handle	20	51620	Interior Bushing
5	OR00208201-1	O-Ring (2.8x2.1)	21	51621	Outer Bushing
6	51606	Hose Plug	22	051620	Ball Bearing(2) (695ZZ)
7	51607	Pin	23	51623	Front Cover
8	51608	Plug	24	51624	Collet
9	70109	O-Ring (2) (9.8x1.9)	25	51625	Collet Nut
10	51610	Screw	26	51626	Muffler Tube
11	51611	Intake Plate	27	51627	Spaner
12	51612	Rotor Spacer	28	51628	Air Hose
13	051613	Ball Bearing (693ZZ)	29	51629	Air Nipple
14	51614	Bearing Plate	30	51630	Hose Ring(2)
15	51615	Rotor	31	51631	Collet Holder
16	51616	Roter Blade(3)	32	51632	Intake Valve